

FTS





0059910 - 0059953



These products must be Earthed

IS1439

230-240V
2.5mm² Min





Acier/Steel	
Standard 0059976 x1	X/T/L 0059979 x1
0059986 x10	0059987 x10
Aluminium	
Standard 0059980 x1	X/T/L 0059981 x1
0059988 x10	0059989 x10


Aluminium	
Standard 0059983 x1	X/T/L 0059984 x1
0059991 x10	0059992 x10

Aluminium	
0059982 x1	0059990 x10


Aluminium	
0059985 x1	0059993 x10



272072



Disconnect from mains supply before replacing the fuse or the lamp.
 Vor dem Einsetzen der Sicherung oder der Lampe Spannungsfreiheit herstellen.
 Débrancher le secteur avant de remplacer le fusible ou l'ampoule.
 Desconectar del suministro de la red, antes de realizar la sustitución del fusible o de la lámpara.
 Voor het vervangen van lamp of zekering, eerst netspanning uitschakelen.
 Koppla bort spänningen före byte av en säkring eller en lampa.



Switch Off
 Abschalten
 Débrancher
 Desconectar
 Uitschakelen
 Släng av

