



2541235
2541236

Disconnect from mains supply before replacing the fuse or the lamp.
Vor dem Einsetzen der Sicherung oder der Lampe Spannungsfreiheit herstellen.
Débrancher le secteur avant de remplacer le fusible ou l'ampoule.
Desconectar del suministro de la red, antes de realizar la sustitución del fusible o de la lámpara.
在更换灯的保险丝之前，要先关闭电源。
在更換燈的保險絲之前，要先關閉電源。
















Switch Off
Abschalten
Débrancher
Desconectar
关闭
關閉

Box Size = 400 x 240 Min




NO INSULATION



Bezel Only
2017413 2017414 2017415

< Millimetres >

Suitable for use indoors
Geeignet für Innenanwendung
Pour un usage interne
Adecuada para uso en interiores
適合于室内使用
適合於室內使用



Myriad is a registered trademark of Concord Lighting Limited.
These products are protected by the following trademark registrations: U.K.-1307938, Benelux-433598, International-525070, Sweden-209849, Finland-105583, Norway-136800, Denmark-6177/1989, Japan-2509585.