



2050750 2052646 2052720 2052726


**Disconnect from mains supply before replacing the fuse or the lamp.**  
 Vor dem Einsetzen der Sicherung oder der Lampe Spannungsfreiheit herstellen.  
**Débrancher le secteur avant de remplacer le fusible ou l'ampoule.**  
 Desconectar del suministro de la red, antes de realizar la sustitución del fusible o de la lámpara.  
**Voor het vervangen van lamp of zekering, eerst netspanning uitschakelen.**  
 Koppla bort spänningen före byte av en säkring eller en lampa.



**Switch Off**  
 Abschalten  
**Débrancher**  
 Desconectar  
**Uitschakelen**  
 Stäng av




If the external cable of this luminaire is damaged, it shall be replaced by a special cable exclusively available from the manufacturer or his agent.




1

i



ii


230-240V~ 50-60Hz  
 2 x 1.0mm² Min.



?


IS1150 Accessories

UP




2


i



ii




iii




3


i




ii




iii



iv



4



Suitable for use indoors

Geeignet für Innenanwendung

Pour un usage interne

Adecuada para uso en interiores

Geschikt voor gebruik binnen

Lämpig för inomhusbruk



This Electrical Product MUST be recycled.

Concord

Havells Sylvania Europe LTD  
 Avis Way, Newhaven East Sussex BN9 0ED UK  
 www.havells-sylvania.com



© Concord Lighting Limited 09.13