

○ 2056146-2056148

■ 2056149-2056151

Isolate from the mains supply before any maintenance.


Vor Wartungsarbeiten von der Netzspannung trennen.

Veillez isoler le luminaire du courant avant toute maintenance.

Aislar de la red eléctrica antes de cualquier operación de mantenimiento.

Koppel het toestel af van de netspanning voor elk onderhoud.


Isolera från elnätet innan något underhåll.




Switch Off
Abschalten
Débrancher
Desconectar
Uitschakelen
Stäng av

○


1



2




3



4




IS1372
IS1373
IS1446
IS1447
IS1520




■


1



2




3



4



IS1372
IS1373
IS1446
IS1447
IS1520



Suitable for use indoors
Geeignet für Innenanwendung
Pour un usage interne
Adecuada para uso en interiores
Geschikt voor gebruik binnen
Lämplig för inomhusbruk



This Electrical Product **MUST** be recycled.