




2042740

Disconnect from mains supply before replacing the fuse or the lamp.
 Vor dem Einsetzen der Sicherung oder der Lampe Spannungsfreiheit herstellen.
Débrancher le secteur avant de remplacer le fusible ou l'ampoule.
 Desconectar del suministro de la red, antes de realizar la sustitución del fusible o de la lámpara.
Voor het vervangen van lamp of zekering, eerst netspanning uitschakelen.
 Koppla bort spänningen före byte av en säkring eller en lampa.



Switch Off
 Abschalten
Débrancher
 Desconectar
Uitschakelen
 Stäng av

Set-Up instruction for CD-ROM: **SYL:MIX I**

1. Insert the CD-ROM into your computer.
The welcome page will appear on the screen and the chance to select your Language.
2. Click on the OK button .
You will have a chance to read the License Agreement, then click on the OK button .
3. The Main Menu will appear. Click on the left icon. 'Select Setup Language' panel will appear, select the appropriate language.
4. Click, on the OK button. The Setup - 'SYL_Mix I Welcome' panel will appear, click on 'Next' to continue.
5. The licence Agreement will appear, click on 'I accept the agreement' then 'Next' to continue.
6. Select Destination Location will appear, click on 'Next' to continue.
7. 'Select Additional Tasks' will appear, click the box if you wish an icon to appear on your desktop, click 'Next' to continue.
8. The 'Ready to Install' Panel will appear, click on 'Install' to continue.
9. The 'Completing the SYL_Mix I Setup Wizard' will appear, click on 'Finish'.
10. The 'Welcome to the SYL:Mix I software' panel will appear, select your favourite operating mode and click on 'OK'.
11. Click on the 'Help' menu on the toolbar for help and instructions for use.

Suitable for use indoors
 Geeignet für Innenanwendung
Pour un usage interne
 Adecuada para uso en interiores
Geschikt voor gebruik binnen
 Lämpig för inomhusbruk



< Millimetres >



This Electrical Product
 MUST be recycled.



10.07

SYLVANIA