





2027457 2027458 2027459
2027469 2029872 2027470

Disconnect from mains supply before replacing the fuse or the lamp.
Vor dem Einsetzen der Sicherung oder der Lampe Spannungsfreiheit herstellen.
Débrancher le secteur avant de remplacer le fusible ou l'ampoule.
Desconectar del suministro de la red, antes de realizar la sustitución del fusible o de la lámpara.
Voor het vervangen van lamp of zekering, eerst netspanning uitschakelen.
Koppla bort spänningen före byte av en säkring eller en lampå.




Switch Off
Abschalten
Débrancher
Desconectar
Uitschakelen
Stäng av







	Dim 'A'	Dim 'B'	Dim 'C'	Dim 'D'
2027457 - 105W 240V	185	40	32	150
2027458 - 105W 230/240V	220	44	40	187
2027459 - 210W 240V	220	44	40	187
2027469 - 105W 230V	185	40	32	150
2029872 - 105W 230V	185	40	32	150
2027470 - 210W 230V	220	44	40	187


105W - 2027457 2027458 2027469 2029872




210W - 2027459 2027470




2027457 2027469 2029872



2027458 2027459 2027470



Suitable for use indoors
Geeignet für Innenanwendung
Pour un usage interne
Adecuada para uso en interiores
Geschikt voor gebruik binnen
Lämplig för inomhusbruk



< Millimetres >